# Operations Guide - GreaseShield®1850 AST-PF

#### Pre-Filter

Solids are collected and de-watered in the removable Pre-Filter basket. The basket must be emptied regularly and cleaned at least once a day. Please ensure a basket is always in place during normal operation.

## Invert Inlet

The internal Automated Solids Transfer (AST) system allows the Invert Inlet to be utilised for incoming effluent. The Invert Inlet is particularly useful when the GreaseShield® is used to service equipment that has low effluent outlet points, such as gravity drained dishwashers.

#### Automated Self Cleaning

Upon activation clean hot water is added into the GreaseShield®, via a WRAS approved water solenoid valve. The Combination of this with the pulsing action of the Grey Water Recirculation pump, agitates and circulates the effluent preventing build of fine sediments in the tank.

(Additional cleaning cycles can be added upon request)



FOG Container

The extracted FOGs are collected in the FOG storage container. This container must be emptied and cleaned at least once a day including the wiper blade. The Max Fill Line should not be exceeded.

Anti-Flood Sensor If the effluent level inside the GreaseShield® becomes to high, a pressure sensor is triggered activating a pump. This pump extracts Grey Water from the bottom of the tank and sent directly to the drain via the grey flexible hose on the back.

0



The standard operation times for a GreaseShield®1850 is from 07:00 hrs until 02:30 hrs.

FOGs & Automated Solids Removal - 5 minutes on followed by 5 minutes off for the duration of the operational period.

**Cleaning** - Once a day, at the start of operation.

(These operation times can be adjusted upon request.)



Automated Solids Transfer The Automated Solids Transfer (AST) system extracts any solids waste from the effluent that enters the GreaseShield®. The AST Auger transports the solids waste from the tank and deposits it in the Solids collection container at the rear of the unit. This container must be emptied and cleaned at least once a day.

> Magnetic Baffle Magnetically treats the effluent to help create an in-situ Bioremediation effect. This effect helps prevent the build-up of scaling in pipework by calcium and metal deposits.

### Grev Water Recirculation

During operational hours when FOG removal takes place, waste thermal water is recirculated from the outlet of the GreaseShield® back to the Inlet. This encourages the reverse flow of effluent and ensures that FOGs are directed towards the FOG Removal Roller.

GreaseShield

#### FOG Removal

A number of co-operating baffles combined the the reverse flow design of the tank, utilises the difference density of grey water and FOGs to separate the effluent. FOGs are directed towards a large, oleophilic (attracts FOGS) and hydrophobic (repels water), FOG Removal Roller. This submerged Roller removes the FOGs from the effluent. A silicone Wiper Blade, with anti-static properties, scrapes the FOGs from the roller and deposits them into the FOG Container.

V2 27/03/2020